

# Comstar Programming Instructions

To program a new or replacement headset follow the steps below, or

GO TO <http://www.eartec.com/cs-prog.html>  
to see video instructions.



## IDENTIFY

1. Start with all system equipment "off" and batteries removed.
2. On the bottom of the Com-Center locate the small compartment door in the center, you will need a small phillips head screwdriver to open this compartment.
3. Once this cover is removed, you will see a series of buttons labeled #1-8. These numbers correspond to the numbers located on the inside of the headset band, on the microphone side, of the wireless headset.
4. Insert the battery or use the A/C power adaptor to supply power to the Com-Center and turn the unit "on". The LED's in the programming compartment will briefly flash red.

## CLEAR

5. The position on the Com-Center that is to be linked to the new or replacement headset must be "cleared" before it is able to accept the program from the headset. This is done by holding down the button on the Com-Center which corresponds to the number of the new headset. When the red LED turns on, release the button. Press the button again until the red LED turns off.

\*NOTE: When clearing a position, the corresponding headset number will also be cleared.

For example:

The #1 on the Com-center would clear both the #1 and #2 positions.

The #3 on the Com-Center would clear both the #3 and #4 positions.

The #5 on the Com-Center would clear both the #5 and #6 positions.

The #7 on the Com-Center would clear both the #7 and #8 positions.

You can easily re-program an existing headset if happens to be located in that cleared corresponding number. You can do this at the end of step 7, below.

## PROGRAM

6. Insert the battery into the headset to be programmed. The blue power LED will begin blinking. Click the volume DOWN 3 times, then press and HOLD the volume UP button.

The blue LED will turn solid. While continuing to HOLD this volume UP button, now also press and hold the corresponding button in the Com-center programming compartment until its red LED turns on. Once both the blue and red LED's are solid, you may release both buttons.

7. The LED's will now remain solid for 2 to 30 seconds. Finally, the LED's on the headset and Com-Center will both go off and then come back on. The programming is now complete. Turn off all headsets before programming another.

\*If further assistance is required, please contact us at 1-800-399-5994, 9-5 Monday through Friday.

GO TO <http://www.eartec.com/cs-prog.html> to see video instructions.